ΕN

DL CYCLONE SECONDARY SHUTOFF

ORIGINAL INSTRUCTIONS



TECHNICAL DATA SHEET

CODE 14450 026 E0



COMPANY WITH QUALITY SYSTEM CERTIFIED BY DNV GL = ISO 9001=

COMPANY WITH ENVIRONMENTAL SYSTEM CERTIFIED BY DNV GL = ISO 14001 =

COMPANY WITH QUALITY SYSTEM CERTIFIED BY DNV GL = UNI EN ISO 3834-2 =



1. General warnings

This technical data sheet contains technical information concerning cyclone secondary shutoff suitable for decompressors of the DL series and the main installation and maintenance instructions.

Complying with the instructions contained in this technical data sheet is crucial for the recognition of warranty against defective parts. Upon receiving the goods, ensure that they are intact and have not been accidentally damaged during transport. In the event parts of the accessory must be replaced, use only genuine spare parts.

2. Technical data

The DL cyclone secondary shutoff is designed to be installed in correspondence with the intake line of decompressors used to create vacuum inside tanks. The cyclone secondary shutoff prevents foreign bodies (liquids or solids) that could carry over past the primary shutoff from entering inside the decompressor by blocking the intake line with a stainless steel floating ball. The cyclone consists of a vertical cylinder, which tangentially receives the flow to be scrubbed at high speed. As a result of centrifugal force, the various elements contained inside the fluid are separated according to their density. The purified fluid is freed through the upper axial outlet, whereas the material to be recovered is collected in the lower part of the cyclone and discharged after each job.


The DL cyclone shutoff is available in the following version:

DL cyclone shutoff, made of Mild steel S235JR and hot-dip galvanizing. code 14450 026 E0

The internal floating ball is made of stainless steel 316.

The following figure shows a schematic diagram of a cyclone secondary shutoff, highlighting the main components.

The DL secondary shutoff are designed to operate in intake (with the decompressor suctioning from the tank) and in compression (decompressor that pump air inside the tank e.g. discharging, the material contained in it) mode.



AIR FLOW VACUUM PRESSURE


The following table shows the main operating parameters concerning maximum flow rate, design pressure and weight of the cyclone secondary shutoff available.

Operating parameters							
Parameter	DL cyclone secondary shutoff						
raiametei	code 14450 026 E0 (Fe)						
MAXIMUM FLOW RATE	900 ÷ 1800 m³/h						
DESIGN PRESSURE	-1 / +1 bar						
WEIGHT	50 Kg						

2/4



DL cyclone secondary shutoff - code 14450 026 E0 (MILD STEEL)



3. Installation

The DL cyclone secondary shutoff is designed to be installed in correspondence of the intake line of a decompressor. To operate correctly, the cyclone secondary shutoff must be installed in a vertical position.

The following figure shows a schematic diagram of a possible installation of the cyclone secondary shutoff (the flow refers to operation in intake/vacuum mode).


To be installed correctly, the cyclone secondary shutoff must be supported by one clamping point.

To allow discharging the collected material, a discharge valve (not supplied) must be installed on the lower end of the secondary shutoff. We recommend positioning the secondary shutoff in order for the discharge area to be accessible.

Extraordinary maintenance operations can require removing the upper cover. This is why we recommend ensuring the necessary space for carrying out this operation, as well as an intake pipe coupling.

The level indicator must be easily accessible to allow checking the filling connection of the secondary shutoff.

During the winter season, the liquid contained in the secondary shutoff must be drained during downtime.





4. Maintenance

Under ordinary use conditions, we recommend discharging the secondary shutoff on a daily basis. In the event of heavy duty conditions (e.g., intake of high and particularly volatile substances), drain every time the level indicator warns that the cyclone secondary shutoff is full. The material is discharged through the valve installed on the lower side.




Recover the drained material and dispose of it in compliance with the standards in force.

We recommend verifying the operation of the overflow valve periodically, ensuring that the floating ball can move freely.

In presence of material drawn in from the tank (e.g. liquids) along the vacuum line, check the integrity and the correct position of the inner double taper seal and of the s/s floating ball. Replace if worn.

DL CYCLONE SECONDARY SHUTOFF



DL cyclone secondary shutoff (mild steel) - code 14450 026 E0

Pos.	Code	Description	Qty	Pos.	Code	Description	Qty
1	1513003100	FLOATING SUPPORT 200X250 ZINC.	1	9	4026150409	SCREW TE M8X30 INOX	2
2	15400235E0	IRON CYCLONE COVER	1	10	4026305404	SELF-LOCKING NUT M8	2
3	15450040E0	IRON CYCLONE BODY	1	11	4026308005	NUT M8 GALV.	12
4	1592000200	STAINLESS STEEL FLOATING BALL Ø150	1	12	4026350706	GROWER WASHER 8 GALV.	12
5	16800002E0	CYCLONE GASKET	1	13	4026357005	FLAT WASHER M8 GALV.	4
6	1680601800	DOUBLE TAPER SEAL D.115	1				
7	4022105001	3" LEVEL INDICATOR	1				
8	4026102808	SCREW TE M8X30 ZINC.	12	Α	1852104300	CONVEYOR D.120 DL220300 (optional)	

e-mail: info@jurop.it